



PND-M06-04

Bloco Distribuidor 4 saídas, rosca M6x1


**PND-M06-06**

Bloco Distribuidor 6 saídas, rosca M6x1



PND-G1/8-xx

Bloco Distribuidor 7 ou 9 saídas, rosca G1/8"




Código	A	B
PND-G1/8-07	80	64
PND-G1/8-09	110	94



PND-G1/8-xx

Bloco Distribuidor 10 ou 12 saídas, rosca G1/8"



Código	A	B
PND-G1/8-10	140	124
PND-G1/8-12	170	154

